




CABINET PARTS

REFRIGERATOR

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
LITERATURE PARTS			13	2217075	Hinge Bottom (2)	25	2155311	Door Closer,
1	2188771	Use & Care Guide	14		Filler, Wrapper			Lower Cam (2)
	2255381	Service & Wiring Sheet		2196094	White	26	489483	Screw
	2305878	Energy Guide		2196150	Biscuit	27		Cabinet (Not a Serviceable Part)
	628370	Modular Icemaker Service Sheet		2196097	Black	28	2203770	Hinge Top, FC
2	2174748	Front Roller (2)	15		Grille	29	2186443	Housing, Water Filter
3	3400517	Screw		2198467W	White	30	2255518	Water Filter
4	2196236	Roller (Rear) (2)		2198467T	Biscuit	31	489500	Screw
5	489427	Screw		2198467B	Black	32		Cap, Water Filter
6	2155013	Clip, Grille	16	489497	Screw		2186494W	White
7	489478	Screw	17	489464	Screw		2186494T	Biscuit
8	2209697	Shim	18	940139	Drain Fitting		2186494B	Black
9	2203771	Hinge Top RC	19	1108438	Extension Tube	33	3400113	Screw
10	8281227	Screw	20	1108439	Clip, Drain Tube	34	3400103	Screw
11	8281149	Screw	21	2188736	Cover, Unit	35	2304249	Plate, Screw
12		Hinge Cover FC	22		Hinge Cover RC	36	2255012	Tube, Filter Outlet
	2203407W	White		2203408W	White	37	2305536	Tube, Filter Inlet
	2203407T	Biscuit		2203408T	Biscuit			
	2203407B	Black		2203408B	Black			
			23	549193	Clamp, Service Cord			
			24	489084	Screw			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

mus	No.
	1
	2
	3
	4
	6
	8
	11
	12
	13
	14
	15
	20
	22
	24
	26
	27
	29
	31
	33
	34
	35
	37

3

REFRIGERATOR SHELF PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCN)




Illus. No.	Part No.	DESCRIPTION
1	2188695	Shelf Assembly, Spillguard (3)
2	2209698	Cover, Crisper
3	2179259	Glass, Cover
4	2179350	Deflector
5	2217039	Cover, Meat Pan
6	2188652	Crisper Pan
7	2188654	Meat Pan
8	2255593	Trim, Crisper Pan
11	2179343	Housing, Humidity Control
12	2179342	Slide, Humidity Control
13	2174150	Glass, Cover
14	2255592	Trim, Meat Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	1115380	Slide, Ice Door
3	2171712	Door, Ice Compartment
4	2196483	Stud Assembly
5	489478	Screw
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
8	8281158	Screw
9	3400893	Screw
10	2176134	Grommet
11	2216111	Freezer Bin
17		Slide, Basket
	2261449	Right Side
	2261448	Left Side
18	486298	Screw
19	1115373	Switch, Rocker Arm
22	3400893	Screw
25	527949	Light Bulb
26	2162085	Light Socket
27	2196207	Stud, Rear
28		Slide, Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw
31	2174265	Shelf (2)
	2174249	Shelf (1)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION
1	2183728	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Solenoid Assembly
4	2149100	Guide, Solenoid
6	1115374	Clip, Wiring
7	2206501	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2196089	Ice Container
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2196295	Auger
28	2209781	Drum
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2171709	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item 6)
	2206716W	White
	2206716T	Biscuit
	2206716B	Black
	2206716L	Stainless-VCM
2	2256101	Door, Compartment
3	489491	Screw
4	2187172	Door Bin (3)
5		Extension, Handle Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
6		Door Gasket, Magnetic (Repair)
	2221300	Mist Beige
	2221311	Black
7		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
8	2195327	Clip
9	3400852	Screw
10		Extension, Handle Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
11	2182178	Door Closer, Upper Cam
12	489420	Screw
13		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
15	2262218	Nameplate
16	2182180	Thimble-Top
21	2177962	Trivet
24	3400012	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

This exploded view diagram illustrates the assembly of a refrigerator door. The central component is the door frame (1), which features internal shelves and drawers. The assembly includes the following parts and their assembly sequence:

- Top Panel (3)**: A vertical panel that fits into the top of the door frame (1).
- Top Trim (5)**: A thin trim piece that fits over the top panel (3).
- Top Mounting Hardware (10, 17, 23)**: Screws (10) and a bracket (23) used to secure the top panel (3) to the frame (1).
- Handle (2)**: A curved handle that is mounted to the front of the door frame (1) using screws (4) and spacers (18).
- Bottom Panel (15)**: A vertical panel that fits into the bottom of the door frame (1).
- Bottom Trim (15)**: A thin trim piece that fits over the bottom panel (15).
- Bottom Mounting Hardware (12, 13, 14, 7)**: A bracket (14) and screws (12, 13, 7) used to secure the bottom panel (15) to the frame (1).
- Door Panel (8)**: The main outer panel of the door, which is attached to the frame (1) using clips (6) and a bracket (19).
- Door Panel Mounting Hardware (16, 19)**: A bracket (19) and screws (16) used to secure the door panel (8) to the frame (1).

11

FREEZER DOOR PARTS


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item 8 And Dispenser Front Parts)
	2255754W	White
	2255754T	Biscuit
	2255754B	Black
	2255754L	Stainless-VCM
2		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
3	2195327	Clip
4	489491	Screw
5		Extension, Handle Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
6	2195919	Trim, Door (4)
7	3400012	Screw
8		Door Gasket, Magnetic (Repair)
	2221301	Mist Beige
	2221312	Black
9	2209680	Trim, Door Shelf
10	488500	Screw
11	2206602	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
15		Extension, Handle Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
16	2195917	End Cap (Left)
17	2182181	Thimble-Top
18	3400852	Screw
19	2195916	End Cap (Right)
23	2154473	Connector

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2256199	Spring, Torsion
5	2196195	Pin
6	2180353	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671T	Biscuit
	2206671B	Black
10	2304317	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (4)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available Order #23)
20	2187408	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2255752W	White
	2255752T	Biscuit
	2255752B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	987121	Shield, Ice Door
27	2188355	Bracket, Dispenser

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	2225834	Fan, Blade	24	2188729	Fan, Motor	52	2205813	Strap
3	2223953	Condenser Assembly	25	1105523	Tray, Evaporator	53	489427	Screw
4	489464	Screw	26	2304288	Heat Shield	55	488649	Screw
5	2208280	Clip, Wire	27	2199167	Drier	63	2209709	Connector, Water Tube
7	8281160	Screw	28	2212191	Compressor (Includes Items 12, 13, 15, 17, 18, 27, 29 & 39) (Also Order 876765 Tube Kit)	Following Parts Not Illustrated and Optional Parts Not Included		
8	2161302	Sleeve						
9	2216997	Insert, Bracket	29	4387765	Wire, Capacitor (Service Only)	978025	Valve, Access (1/4")	
10	2216914	Clip, Condenser	30	2160501	Unit Mounting Frame	978026	Valve, Access (5/16")	
11	2261599	Tube, Condenser to Heat Loop	31	2187783	Unit, Harness	978027	Valve, Access (3/8")	
12	4387731	Cover (Service Compressor Only)	32	2181929	Fan, Motor Bracket	978028	Valve, Access (1/2")	
13	2187145	Overload (Service Only)	33	2188174	Heater, Defrost	978029	Valve, Access (5/8")	
14	2223314	Clip, Retaining	34	2304287	Clip	978030	Valve, Access (3/4")	
15	2188829	Start-Device, Combination (Start Relay and Overload) for Production Compressor Only	37	489373	Screw	876764	Valve, Access (3/16")	
16	2205764	Tube Suction	39	1100826	Production Service	REFRIGERANT CHARGE		
17	999532	Capacitor Production	40	489340	Screw			
	1118576	Service	41	2196202	Air Baffle	5.0 oz. (R-134A)		
18	2183454	Relay (Service Only)	42	2155547	Clip, Heat Shield			
21	489478	Screw	43	2182057	Unit Cover, Bottom			
22	2188822	Evaporator	44	489396	Clip			
23	2161324	Clamp	48	2149718	Unit Mounting Rail			
			49	8281232	Screw			
			50	2186496	Guard, Fan			



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS


For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



Illus. No.	Part No.	DESCRIPTION
1	2216013	Control Box
2	1110629	Mounting Bracket
3	3196537	Screw (4)
4	2149705	Light Switch
5	2200096	Cover, Light Lens
6	2252150	Control Board Assembly
7	489398	Screw (2)
8	940014	Hole Plug
9	2198202	Thermostat Assembly


Illus. No.	Part No.	DESCRIPTION
10	487869	Screw
11	2182195	Cam Assembly
12	1110560	Bearing Body
14	2196062	Clip, Damper Control
15	1110559	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
18	2196001	Thermostat, Barrier
19	527949	Light Bulb

Illus. No.	Part No.	DESCRIPTION
20	8201594	Control Box Harness
21	1115374	Clip, Wiring
22	1115375	Clip, Wiring
23	1123960	Connecting Rod
24	489285	Fastener, Push-On
25	2261173	Escutcheon, Control Box
26	2182111	Thermostat knob
27	2197871	Knob, Air Control
29	489203	Spring Washer
30	2213462	Harness, Indicator Light

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCN)

Illus. No.	Part No.	DESCRIPTION
1	489084	Screw
2	2209774	Chute, Water
5	628379	Clip, Fuse
7	2181943	Tube, Water
9	489478	Screw
10	2188708	Filter Valve Asm
14	2208136	Clip, Tube
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	627843	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
31	2209675	Shut Off Arm
33	628320	Bracket
35	626653	Module Assembly (Includes Items 37 and 38)
36	488208	Screw
37	627811	Motor
38	489136	Screw
100	4317943	Complete Ice maker Assembly

PARTS NOT ILLUSTRATED

For Models: ED2GHEXNQ00, ED2GHEXNT00, ED2GHEXNB00, ED2GHEXNL00
(White) (Biscuit) (Black) (Stainless-VCM)

Illus. No.	Part No.	DESCRIPTION
Parts Not Illustrated and Optional Parts (Not Included)		
Customer Touch-Up Material		
	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*350956	Enamel, Almond (12 Oz. Spray Can)
	72017	Brush Touch-Up Kit (White)
	72107	Brush Touch-Up Kit (Almond)
	72032	Brush Touch-up Kit (Black)

***Important:** The spray paint is not to be used where the paint may make contact with the door gaskets.

Illus. No.	Part No.	DESCRIPTION
Miscellaneous		
	8129	Coil Brush
	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)
	876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch-Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1-1/4 Oz.)
	606755	Bag, Insulation (36-5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2209779	Ice Container Assembly

Illus. No.	Part No.	DESCRIPTION
Refinishing Material		
	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

TORX SCREW WRENCH

1117510 Torx Key

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST